

Aastra 6771, 6773, 6775 (OpenPhone 71, 73, 75)

Kurzbedienungsanleitung: Bedienung der Tasten

Taste	Kurzer Druck	Langer Druck	
ABC	Wählen aus dem Telefonbuch	Umschalten der Display- Sprachen	
i	Listeneinträge aufrufen: Anrufe, Kurznachrichten, E-Mails, Sprachboxnachrichten	Anzeige der aktiven Funktionen	
C	Löscht einen Listeneintrag oder das Zeichen links des Cursors	Löscht ganze Liste oder ganze Zeile	
	Liste der momentan möglichen Funktionen	Gesamtmenü	
Gesprächstaste	Belegen der Taste	Liste der Tastenfunktionen	
Funktionstaste	Ausführung der Funktion	Programmieren oder Ändern /Löschen der Funktion	
	Auf Headset-Betrieb umschalten		
	Öffnet die Liste mit den zuletzt gewählten Nummern zwecks Wiederwahl		
8	Schaltet das Freisprechmikrofon und das Mikrofon des Hörers aus		
-+	Je nach Betriebszustand:		
	 im Ruhezustand: Display-Kontrast einstellen 		
	 im Rufzustand: Tonruflautstärke einstellen 		
	 im Gespräch: Lautstärke verändern (Hörer, Lautsprecher oder Kopfhörer bei einem Headset) 		
	 beim Editieren: Cursor links / rechts bewegen 		
	– im Menü: Funktionen aktivieren / deaktivieren		



Aastra 6771, 6773, 6775 (OpenPhone 71, 73, 75)

Kurzbedienungsanleitung: Bedienung der Tasten

Taste	Kurzer Druck	Langer Druck	
ABC	Wählen aus dem Telefonbuch	Umschalten der Display- Sprachen	
ī	Listeneinträge aufrufen: Anrufe, Kurznachrichten, E-Mails, Sprachboxnachrichten	Anzeige der aktiven Funktionen	
C	Löscht einen Listeneintrag oder das Zeichen links des Cursors	Löscht ganze Liste oder ganze Zeile	
	Liste der momentan möglichen Funktionen	Gesamtmenü	
Gesprächstaste	Belegen der Taste	Liste der Tastenfunktionen	
Funktionstaste	Ausführung der Funktion	Programmieren oder Ändern /Löschen der Funktion	
	Auf Headset-Betrieb umschalten		
	Öffnet die Liste mit den zuletzt gewählten Nummern zwecks Wiederwahl		
Ø	Schaltet das Freisprechmikrofon und das Mikrofon des Hörers aus		
- t	Je nach Betriebszustand:		
	- im Ruhezustand: Display-Kontrast einstellen		
	- im Rufzustand: Tonruflautstärke einstellen		
	 im Gespräch: Lautstärke verändern (Hörer, Lautsprecher oder Kopfhörer bei einem Headset) 		
	 beim Editieren: Cursor links / rechts bewegen 		
	– im Menü: Funktionen aktivieren / deaktivieren		



Aastra 6771, 6773, 6775 (OpenPhone 71, 73, 75)

Short User Guide: Operating the keys

Key	Short press	Long press
ABC	Dialling from the telephone book	Switching to other display languages
i	Consult list entries (calls, messages, e-mails, voicebox messages)	Indication of active functions
C	Deletes list entry or charac- ters on the left cursor side	Deletes the entire list or row
	List of current possible functions	Main menu
Call key	Assigning of key	List of functions for this key
Function key	Effecting the function	Program or alter the function
0	Switches to headset operation	
	List of the last dialled numbers	
8	Switches the microphone to mute-mode	
+	Depending on mode: - in idle mode: Contrast setting - calling mode: Setting ringer volume - during call: Setting handset/speaker volume - inserting mode: Moving cursor left/right - in menu mode: Activate/deactivate functions	



Aastra 6771, 6773, 6775 (OpenPhone 71, 73, 75)

Short User Guide: Operating the keys

Key	Short press	Long press	
ABC	Dialling from the telephone book	Switching to other display languages	
	Consult list entries (calls, messages, e-mails, voicebox messages)	Indication of active functions	
C	Deletes list entry or characters on the left cursor side	Deletes the entire list or row	
	List of current possible functions	Main menu	
Call key	Assigning of key	List of functions for this key	
Function key	Effecting the function	Program or alter the function	
0	Switches to headset operation		
	List of the last dialled numbers		
8	Switches the microphone to mute-mode		
-+	Depending on mode:		
	 in idle mode: Contrast setting 		
	 calling mode: Setting ringer volume 		
	 during call: Setting handset/speaker volume 		
	 inserting mode: Moving cursor left/right 		
	in menu mode: Activate/deactivate functions		

Aastra 6771, 6773, 6775 (OpenPhone 71, 73, 75)

Short User Guide: Basic functions

Dialling

Insert the telephone number, lift the handset or press the hands-free/open-listening key or press the headset key.

Taking on a call

Lift the handset or press the flashing call key —— or press the headset key — .

Finish a call

On-Hook the handset or press the disconnect key $\ \ \ \ \ \ \ \ \ \ \ \ \ \ \$ or press the headset key $\ \ \ \ \ \ \ \ \ \ \ \ \ \ \$

Transferring

Press during the call the consultation key and dial then the other subscriber number. You can now transfer the call after announcing your termination by onhooking the handset.

Hands-Free Mode

- Press the hands-free key in the idle mode.
- The hands-free mode can be terminated by lifting the handset or by repeated press of the hands-free key _____.
- Switching to hand-free mode during a call: Press the hands-free key and keep it depressed. Replace the handset. After that release the hands-free key

Open-Listening Mode

- Press the open-listening key during a call with your handset.
- The loud hearing can be terminated by a repeated press of the open-listening key <</p>
- Hanging up ends the call.

Aastra Telecom Schweiz AG Status: 11.06.2009 Subject to changes

Aastra 6771, 6773, 6775 (OpenPhone 71, 73, 75)

Short User Guide: Basic functions

Dialling

Insert the telephone number, lift the handset or press the hands-free/open-listening key or press the headset key.

Taking on a call

Lift the handset or press the flashing call key or press the headset key

Finish a call

On-Hook the handset or press the disconnect key $\ \ \ \ \ \ \ \ \ \ \ \ \ \$ or press the headset key $\ \ \ \ \ \ \ \ \ \$

Transferring

Press during the call the consultation key <u>and dial then the other subscriber</u> number. You can now transfer the call after announcing your termination by onhooking the handset.

Hands-Free Mode

- Press the hands-free key in the idle mode.
- The hands-free mode can be terminated by lifting the handset or by repeated press of the hands-free key _____.
- Switching to hand-free mode during a call: Press the hands-free key and keep it depressed. Replace the handset. After that release the hands-free key

Open-Listening Mode

- Press the open-listening key during a call with your handset.
- The loud hearing can be terminated by a repeated press of the open-listening key <a>¬.
- Hanging up ends the call.

Aastra 6771, 6773, 6775 (OpenPhone 71, 73, 75)

Kurzbedienungsanleitung: Grundfunktionen

Wähler

Rufnummer eintippen, Hörer abheben oder Freisprechen-/Lauthörentaste drücken oder Headset-Taste drücken.

Gespräch annehmen

Hörer abheben oder die blinkende Gesprächstaste —→ drücken oder Headset-Taste ⊙ drücken.

Gespräch beenden

Hörer auflegen oder Trennen-Taste odrücken oder Headset-Taste drücken.

Vermitteln

Während des Gespräches die Rückfragetaste

m drücken und den gewünschten Teilnehmer anrufen. Gespräch, nach der Ankündigung, durch Auflegen des Hörers übergeben.

Freisprechen

- Im Ruhezustand die Freisprechen-Taste drücken.
- Das Freisprechen kann durch Abheben des Hörers oder nochmaliges Drücken der Freisprechen-Taste beendet werden.
- Während eines Gespräches auf Freisprechen umschalten: Freisprechen-Taste drücken und diese gedrückt halten. Hörer auflegen und erst danach die Freisprechen-Taste wieder loslassen.

Lauthören

- Das Lauthören kann durch nochmaliges Drücken der Lauthören-Taste deendet werden.
- Das Auflegen des Hörers beendet das Gespräch.

Aastra Telecom Schweiz AG Stand: 11.06.2009 Änderungen vorbehalten

Aastra 6771, 6773, 6775 (OpenPhone 71, 73, 75)

Kurzbedienungsanleitung: Grundfunktionen

Wähler

Rufnummer eintippen, Hörer abheben oder Freisprechen-/Lauthörentaste drücken oder Headset-Taste drücken.

Gespräch annehmen

Gespräch beenden

Hörer auflegen oder Trennen-Taste 🕶 drücken oder Headset-Taste 🙃 drücken.

Vermitteln

Während des Gespräches die Rückfragetaste

muter den gewünschten Teilnehmer anrufen. Gespräch, nach der Ankündigung, durch Auflegen des Hörers übergeben.

Freisprechen

- Das Freisprechen kann durch Abheben des Hörers oder nochmaliges Drücken der Freisprechen-Taste beendet werden.
- Während eines Gespräches auf Freisprechen umschalten: Freisprechen-Taste drücken und diese gedrückt halten. Hörer auflegen und erst danach die Freisprechen-Taste dwieder loslassen.

Lauthören

- Lauthören-Taste drücken während eines Gesprächs mit dem Hörer.
- Das Lauthören kann durch nochmaliges Drücken der Lauthören-Taste deendet werden.
- Das Auflegen des Hörers beendet das Gespräch.